

Eurosport "RX 150 XE" BODY PARTS							
Mirror							
Num.	Part No.	Description	Q'ty	Price	Measure	Model	Category
1	LY-010300	Left back view mirror	1		each	RX 150 XE	Mirror
2	LY-020200	Right back view mirror	1		each	RX 150 XE	Mirror
3	LY-010300	Rubber cover of bolt	2		each	RX 150 XE	Mirror
4	GB70-86	Bolt 8*40	2		each	RX 150 XE	Mirror

F.1 - Mirror

Front cover & Front Light							
Num.	Part No.	Description	Q'ty	Price	Measure	Model	Category
1	LY-020100	Front cover	1		each	RX 150 XE	Front cover & Front Light
2	LY-020200	Headlight assy.	1		each	RX 150 XE	Front cover & Front Light
3	LY-020300	Bulb of headlight	1		each	RX 150 XE	Front cover & Front Light
4	LY-020400	Bulb of front position light	1		each	RX 150 XE	Front cover & Front Light
5	GB845-86	Self-tapping screw 3T4.8x16	4		each	RX 150 XE	Front cover & Front Light
6	GB845-86	Self-tapping screw 3T4.8x12	4		each	RX 150 XE	Front cover & Front Light
7	LY-020500	Clip# 4.2	4		each	RX 150 XE	Front cover & Front Light
8	LY-020600	Small plastic cover	1		each	RX 150 XE	Front cover & Front Light

F.2 - Front cover & Front Light

HandCover							
Num.	Part No.	Description	Q'ty	Price	Measure	Model	Category
1	LY-030100	Front cover, handlebar	1		each	RX 150 XE	HandCover
2	LY-030200	Protection Cover, Left	1		each	RX 150 XE	HandCover
3	LY-030300	Protection Cover, Right	1		each	RX 150 XE	HandCover
4	LY-030400	Front turn signal, Left	1		each	RX 150 XE	HandCover
5	LY-030500	Front turn signal, Right	1		each	RX 150 XE	HandCover
6	LY-030600	Clip# 4.2	1		each	RX 150 XE	HandCover
7	GB845-86	Self-tapping screw 3T4.2x16	2		each	RX 150 XE	HandCover
8	GB845-86	Self-tapping screw 3T4.8x12	4		each	RX 150 XE	HandCover
9	GB18-3000	Screw M5x25	4		each	RX 150 XE	HandCover
10	LY-030600	Cover front brake	1		each	RX 150 XE	HandCover
11	LY-030700	Case Front Cover	1		each	RX 150 XE	HandCover
12	LY-030800	Plastic Bolt	4		each	RX 150 XE	HandCover

F.3 - HandCover

Speedometer							
Num.	Part No.	Description	Q'ty	Price	Measure	Model	Category
1	LY-040100	Speedometer Cover	1		each	RX 150 XE	Speedometer
2	LY-040200	Speedometer	1		each	RX 150 XE	Speedometer
3	LY-040300	Speedometer wire assy	1		each	RX 150 XE	Speedometer
4	LY-040400	Bulb of speedometer 12V 1.7W	5		each	RX 150 XE	Speedometer
5	LY-040500	Flasher	1		each	RX 150 XE	Speedometer
6	LY-040600	Light shifting switch	1		each	RX 150 XE	Speedometer
7	LY-040700	Switch off turn signal	1		each	RX 150 XE	Speedometer
8	LY-040800	Switch of brake light	1		each	RX 150 XE	Speedometer
9	LY-040900	Light switch	1		each	RX 150 XE	Speedometer
10	LY-041000	Electric starting up button	1		each	RX 150 XE	Speedometer
11	LY-041100	Horn button	1		each	RX 150 XE	Speedometer
12	GB845-86	Self-tapping screw 3T4.8x16	3		each	RX 150 XE	Speedometer
13	GB845-86	Self-tapping screw 3T4.2x12	7		each	RX 150 XE	Speedometer

F.4 - Speedometer

Steering Handlebar							
Num.	Part No.	Description	Q'ty	Price	Measure	Model	Category
1	LY-050100	Handlebar	1		each	RX 150 XE	Steering Handlebar
2	LY-050200	Left grip	1		each	RX 150 XE	Steering Handlebar
3	LY-050300	Right grip	1		each	RX 150 XE	Steering Handlebar
4	LY-050400	Horn throttle	1		each	RX 150 XE	Steering Handlebar
5	LY-050500	Left brake base	1		each	RX 150 XE	Steering Handlebar
6	LY-050600	Left brake lever	1		each	RX 150 XE	Steering Handlebar
7	LY-050700	Left brake fixing buckle	1		each	RX 150 XE	Steering Handlebar

8	GB5786-86	Bolt M6x16	1		each	RX 150 XE	Steering Handlebar
9	LY-050800	Bolt M6x25	1		each	RX 150 XE	Steering Handlebar
10	GB5733-86	Nut M6	1		each	RX 150 XE	Steering Handlebar
11	GB5787-86	Hexagon bolt M10x50	1		each	RX 150 XE	Steering Handlebar
12	GB5763-86	Hexagon nut M10	1		each	RX 150 XE	Steering Handlebar
13	LY-050900	Bushing of handlebar	1		each	RX 150 XE	Steering Handlebar

F.5 - Steering Handlebar




Front Panel							
Num.	Part No.	Description	Qty	Price	Measure	Model	Category
1	LY-060100	Bottom of front panel	1		each	RX 150 XE	Front Panel
2	LY-060200	Left side cover	1		each	RX 150 XE	Front Panel
3	LY-060300	Right side cover	1		each	RX 150 XE	Front Panel
4	LY-060400	Clip 4.2	6		each	RX 150 XE	Front Panel
5	GB845-85	Self-tapping screw 3T4.8x12	4		each	RX 150 XE	Front Panel

F.6 - Front Panel




Tool Kit Box							
Num.	Part No.	Description	Qty	Price	Measure	Model	Category
1	LY-070100	Tool box	1		each	RX 150 XE	Tool Kit Box
2	LY-070200	Hook of tool box	1		each	RX 150 XE	Tool Kit Box
3	GB845-85	Self-tapping screw 3T4.8x25	2		each	RX 150 XE	Tool Kit Box
4	LY-070300	Clip 4.2	4		each	RX 150 XE	Tool Kit Box
5	GB5787-86	Hexagon bolt M6x20	2		each	RX 150 XE	Tool Kit Box
6	GB5787-86	Hexagon bolt M6x16	2		each	RX 150 XE	Tool Kit Box
7	GB5763-86	Hexagon nut M6	1		each	RX 150 XE	Tool Kit Box
8	GB845-85	Self-tapping screw 3T4.2x16	10		each	RX 150 XE	Tool Kit Box
9	GB845-85	Self-tapping screw 3T4.8x16	2		each	RX 150 XE	Tool Kit Box
10	LY-070400	Lock of tool box	1		each	RX 150 XE	Tool Kit Box
11	LY-070500	Clip spring	1		each	RX 150 XE	Tool Kit Box

F.7 - Tool Kit Box



Front Wheel Fender							
Num.	Part No.	Description	Qty	Price	Measure	Model	Category
1	LY-080100	Front wheel fender A	1		each	RX 150 XE	Front Wheel Fender
2	LY-080200	Front wheel fender B	1		each	RX 150 XE	Front Wheel Fender
3	GB5787-86	Hexagon bolt M6x12	6		each	RX 150 XE	Front Wheel Fender
4	LY-080300	Clip M6	1		each	RX 150 XE	Front Wheel Fender
5	LY-080400	Screw M6x12	1		each	RX 150 XE	Front Wheel Fender
6	LY-080500	Locket card	1		each	RX 150 XE	Front Wheel Fender
7	LY-080600	Side reflector	2		each	RX 150 XE	Front Wheel Fender

F.8 - Front Wheel Fender



Front Wheel							
Num.	Part No.	Description	Qty	Price	Measure	Model	Category
1	LY-090100	Front wheel	1		each	RX 150 XE	Front Wheel
2	LY-090200	Front tire	1		each	RX 150 XE	Front Wheel
3	LY-090300	Valve stem	1		each	RX 150 XE	Front Wheel
4	LY-090400	Bushing 13x4 2Dx20	1		each	RX 150 XE	Front Wheel
5	LY-090500	Front axle M12-2x45	1		each	RX 150 XE	Front Wheel
6	GB5763-86	Hexagon nut M12	1		each	RX 150 XE	Front Wheel
7	LY-090600	Brake disk	1		each	RX 150 XE	Front Wheel
8	LY-090700	Disk control	1		each	RX 150 XE	Front Wheel
9	LY-090100	Gen of speedometer	1		each	RX 150 XE	Front Wheel
10	GB5787-86	Hexagon bolt M8x25	2		each	RX 150 XE	Front Wheel
11	GB5787-86	Hexagon bolt M6x42	1		each	RX 150 XE	Front Wheel
12	GB70-85	Bolt M8x25	3		each	RX 150 XE	Front Wheel

F.9 - Front Wheel



Seat							
Num.	Part No.	Description	Qty	Price	Measure	Model	Category
1	LV-100100	Rubber floor mat	1		each	RX 150 XE	Seat
2	LV-100300	Left rubber mat plug	1		each	RX 150 XE	Seat
3	LV-100300	Right rubber mat plug	1		each	RX 150 XE	Seat
4	GB845-85	Self tapping screw ST4.2x16	1		each	RX 150 XE	Seat
5	LV-100400	Seat	1		each	RX 150 XE	Seat
6	LV-100500	Seat pin	1		each	RX 150 XE	Seat
7	GB5787-88	Hexagon bolt M6x16	1		each	RX 150 XE	Seat

F.10 - Seat



Luggage box							
Num.	Part No.	Description	Qty	Price	Measure	Model	Category
1	LV-110100	Luggage box assy	1		each	RX 150 XE	Luggage box
2	LV-110200	Cover for luggage box	1		each	RX 150 XE	Luggage box
3	LV-110300	Front shroud	1		each	RX 150 XE	Luggage box
4	LV-110400	Small cover of front shroud	1		each	RX 150 XE	Luggage box
5	GB845-85	Self tapping screw ST4.8x16	5		each	RX 150 XE	Luggage box
6	LV-110500	Clip 4.2	1		each	RX 150 XE	Luggage box
7	GB6177-86	Hexagon nut M6	2		each	RX 150 XE	Luggage box

F.11 - Luggage box



Footboard							
Num.	Part No.	Description	Qty	Price	Measure	Model	Category
1	LY-120100	Footboard	1		each	RX 150 XE	Footboard
2	LY-120200	Battery cover	1		each	RX 150 XE	Footboard
3	LY-120300	Self-tapping screw 3T4.2x16	2		each	RX 150 XE	Footboard
4	LY-120400	Plastic plate left	1		each	RX 150 XE	Footboard
5	LY-120500	Plastic plate right	1		each	RX 150 XE	Footboard
6	LY-120600	Frame fender	1		each	RX 150 XE	Footboard
7	GB5787-86	Hexagon bolt M6x20	2		each	RX 150 XE	Footboard
8	GB5787-86	Hexagon bolt M6x20	2		each	RX 150 XE	Footboard
9	GB5787-86	Screw M6x16	2		each	RX 150 XE	Footboard
10	GB5787-86	Hexagon bolt M6x12	4		each	RX 150 XE	Footboard
11	GB844-85	Self-tapping screw 3T4.8x16	14		each	RX 150 XE	Footboard
12	LY-120700	Clif 4.2	11		each	RX 150 XE	Footboard

F.12 - Footboard



Protecting cover							
Num.	Part No.	Description	Qty	Price	Measure	Model	Category
1	011000001	Left protecting plate	1		each	RX 150 XE	Protecting cover
2	011000002	Right protecting plate	1		each	RX 150 XE	Protecting cover
3	011000003	Small plastic plate, left	1		each	RX 150 XE	Protecting cover
4	011000004	Small plastic plate, right	1		each	RX 150 XE	Protecting cover
5	011000005	Rear plastic plate	1		each	RX 150 XE	Protecting cover
6	011000006	Connecting plate of taillight	1		each	RX 150 XE	Protecting cover
7	090700006	Seat lock	1		each	RX 150 XE	Protecting cover
8	090700003	Seat lock bracket	1		each	RX 150 XE	Protecting cover
9	010500001	Clip spring of seat lock	1		each	RX 150 XE	Protecting cover
10	000000035	Screw M6x12	2		each	RX 150 XE	Protecting cover
11	000000023	Self-tapping screw 3T4.8x16	4		each	RX 150 XE	Protecting cover
12	000000025	Self-tapping screw 3T4.2x12	6		each	RX 150 XE	Protecting cover
13	000000024	Self-tapping screw 3T4.2x16	2		each	RX 150 XE	Protecting cover
14	000000026	Clif 4.2	6		each	RX 150 XE	Protecting cover
15	011000007	Small protecting plate,Left	1		each	RX 150 XE	Protecting cover
16	011000008	Small protecting plate,Right	1		each	RX 150 XE	Protecting cover

F.13 - Protecting cover



Rear rack cover							
Num.	Part No.	Description	Qty	Price	Measure	Model	Category
1	LY-140100	Rear rack	1		each	RX 150 XE	Rear rack cover
2	LY-140100	Cover rear rack	1		each	RX 150 XE	Rear rack cover
3	GB5787-86	Hexagon bolt M6x12	6		each	RX 150 XE	Rear rack cover
4	GB5787-86	Hexagon bolt M6x20	2		each	RX 150 XE	Rear rack cover
5	GB5787-86	Hexagon bolt M6x16	2		each	RX 150 XE	Rear rack cover

F.14 - Rear rack cover



Tail light							
Num.	Part No.	Description	Qty	Price	Measure	Model	Category
1	LY-150100	Tail light assy	1		each	RX 150 XE	Tail light
2	LY-150101	Bulb of tail light	1		each	RX 150 XE	Tail light
3	LY-150102	Bulb of rear turn light	2		each	RX 150 XE	Tail light
4	LY-150103	Bulb of license light	1		each	RX 150 XE	Tail light
5	LY-150201	Side reflector	2		each	RX 150 XE	Tail light
6	LY-150200	Rear reflector	1		each	RX 150 XE	Tail light
7	GB6177.86	Hexagon bolt M6x16	4		each	RX 150 XE	Tail light
8	LY-150100	Clip F 4.2	2		each	RX 150 XE	Tail light
9	GB971.85	Washer F 6x18	1		each	RX 150 XE	Tail light
10	GB6177.86	Hexagon nut M6	2		each	RX 150 XE	Tail light
11	GB971.85	Washer F 6x12	1		each	RX 150 XE	Tail light
12	GB6177.86	Hexagon bolt M6x16	1		each	RX 150 XE	Tail light

F.15 - Tail light




Fuel tank							
Num.	Part No.	Description	Qty	Price	Measure	Model	Category
1	LY-160100	Fuel tank	1		each	RX 150 XE	Fuel tank
2	LY-160200	Fuel tank cap	1		each	RX 150 XE	Fuel tank
3	LY-160300	Fuel sensor unit	1		each	RX 150 XE	Fuel tank
4	LY-160400	Plate fuel sensor unit	1		each	RX 150 XE	Fuel tank
5	LY-160500	Washer fuel sensor unit	1		each	RX 150 XE	Fuel tank
6	LY-160600	Fuel petcock	1		each	RX 150 XE	Fuel tank
7	LY-160700	Oil filter	1		each	RX 150 XE	Fuel tank
8	LY-160800	Fuel tank plate	1		each	RX 150 XE	Fuel tank
9	GB5797.86	Hexagon bolt M6x16	2		each	RX 150 XE	Fuel tank
10	LY-160900	Seat lock bracket	1		each	RX 150 XE	Fuel tank
11	LY-161000	Seat lock cable	1		each	RX 150 XE	Fuel tank
12	LY-161001	Hexagon bolt M6x16	5		each	RX 150 XE	Fuel tank
13	LY-161002	Clip spring F	6		each	RX 150 XE	Fuel tank
14	LY-161003	Clip spring F	2		each	RX 150 XE	Fuel tank
15	LY-161004	Oil pipe F 4.5x F 8.5	1		each	RX 150 XE	Fuel tank
16	LY-161005	Oil pipe F 4.5x F 8.5	1		each	RX 150 XE	Fuel tank

F.16 - Fuel tank




Air Cleaner							
Num.	Part No.	Description	Q'ty	Price	Measure	Model	Category
1	490013CCT000	CAP AIR CLEANER	1		each	RX 150 XE	Air Cleaner
2	49200CCT000	FILTER ASSY	1		each	RX 150 XE	Air Cleaner
3	49013CCT000	DUST SEAL	1		each	RX 150 XE	Air Cleaner
4	49016CCT000	CLIP COMP. 1	1		each	RX 150 XE	Air Cleaner
5	49014CCT000	CAP AIR CLEANER	1		each	RX 150 XE	Air Cleaner
6	49005CCT000	TUBE AIR OUTLET	1		each	RX 150 XE	Air Cleaner
7	49340CCT000	CLIP COMP. 2	1		each	RX 150 XE	Air Cleaner
8	805004001000	TAPPING SCREW STR 2X30	8		each	RX 150 XE	Air Cleaner
9	B1306001605	SCREW EX16MM	3		each	RX 150 XE	Air Cleaner
10	49000CCT000	AIR FILTER ASSY	1		each	RX 150 XE	Air Cleaner

F.17 - Air Cleaner




Electric							
Num.	Part No.	Description	Q'ty	Price	Measure	Model	Category
1	LY-180100	Wire Assy	1		each	RX 150 XE	Electric
2	LY-180200	"+" cable	1		each	RX 150 XE	Electric
3	LY-180300	"-" cable	1		each	RX 150 XE	Electric
4	LY-180400	Fuse	2		each	RX 150 XE	Electric
5	LY-180500	Fuse box	1		each	RX 150 XE	Electric
6	LY-180600	CDI Assy	1		each	RX 150 XE	Electric
7	LY-180700	Relay Assy	1		each	RX 150 XE	Electric
8	LY-180800	High voltage wire Assy	1		each	RX 150 XE	Electric
9	LY-180900	Ignition lock	1		each	RX 150 XE	Electric
10	LY-181000	Ignition key	2		each	RX 150 XE	Electric
11	LY-181100	Anti-theft controller	1		each	RX 150 XE	Electric
12	LY-180100	Horn Assy	1		each	RX 150 XE	Electric
13	LY-180200	Rectifier Assy	1		each	RX 150 XE	Electric
14	LY-180300	Hexagon bolt M6x12	1		each	RX 150 XE	Electric
15	LY-180400	Hexagon bolt M6x16	4		each	RX 150 XE	Electric
16	LY-180500	Bracket	1		each	RX 150 XE	Electric
17	LY-180600	Hexagon nut M6	1		each	RX 150 XE	Electric
18	LY-180700	Horn bracket	1		each	RX 150 XE	Electric
19	LY-180800	Screw M5x20	1		each	RX 150 XE	Electric
20	LY-180900	Relay Assy	1		each	RX 150 XE	Electric

F.18 - Electric



Electric II							
Num.	Part No.	Description	Q'ty	Price	Measure	Model	Category
1	LY-190100	Rear brake cable	1		each	RX 150 XE	Electric II
2	LY-190200	Throttle cable	1		each	RX 150 XE	Electric II
3	LY-190300	Speedometer cable	1		each	RX 150 XE	Electric II
4	LY-190400	Front left speed lock	1		each	RX 150 XE	Electric II

F.19 - Electric II




Steering							
Num.	Part No.	Description	Q'ty	Price	Measure	Model	Category
1	LY-200100	Steering column	1		each	RX 150 XE	Steering
2	LY-200200	Washer 25x40	1		each	RX 150 XE	Steering
3	LY-200300	Upper cover bearing race	1		each	RX 150 XE	Steering
4	LY-200400	Under cover bearing race	1		each	RX 150 XE	Steering
5	LY-200500	Upper cover bearing bowl	1		each	RX 150 XE	Steering
6	LY-200600	Ball 4.8	1		each	RX 150 XE	Steering
7	LY-200700	Under cover bearing bowl	1		each	RX 150 XE	Steering
8	LY-200800	Lock nut	1		each	RX 150 XE	Steering
9	LY-200900	Nut	1		each	RX 150 XE	Steering
10	LY-201000	Hexagon bolt M10x40	4		each	RX 150 XE	Steering
11	LY-201100	Front left absorber Assy	1		each	RX 150 XE	Steering
12	LY-201200					RX 150 XE	Steering

F.20 - Steering



Frame							
Num.	Part No.	Description	Q'ty	Price	Measure	Model	Category
1	LY-210100	Frame axcy	1		each	RX 150 XE	Frame
2	LY-210200	Side stand	1		each	RX 150 XE	Frame
3	LY-210300	Spring of side stand	1		each	RX 150 XE	Frame
4	LY-210400	Bolt, side stand	1		each	RX 150 XE	Frame
5	LY-210500	Hanger	1		each	RX 150 XE	Frame
6	GB5787-86	Hexagon bolt M10x40	2		each	RX 150 XE	Frame
7	GB5787-86	Axes of hanger	1		each	RX 150 XE	Frame
8	GB5763-86	Hexagon nut M10	1		each	RX 150 XE	Frame
9	LY-210600	Buffer of hanger	2		each	RX 150 XE	Frame
10	LY-210700	Center stand	1		each	RX 150 XE	Frame
11	LY-210800	Spring of center stand	1		each	RX 150 XE	Frame
12	GB5793-86	Hexagon bolt M10x25	1		each	RX 150 XE	Frame
13	LY-210900	Bushing	1		each	RX 150 XE	Frame
14	LY-211000	Buffer of center stand	1		each	RX 150 XE	Frame
15	LY-211100	Bolt M6x25	1		each	RX 150 XE	Frame
16	GB5763-86	Hexagon nut M6	1		each	RX 150 XE	Frame
17	LY-211200	Left bracket, footboard	1		each	RX 150 XE	Frame
18	LY-211300	Right bracket, footboard	1		each	RX 150 XE	Frame
19	LY-211400	Bracket, luggage box	1		each	RX 150 XE	Frame
20	GB5763-86	Hexagon nut M6	1		each	RX 150 XE	Frame

F.21 - Frame



Rear absorber							
Num.	Part No.	Description	Q'ty	Price	Measure	Model	Category
1	LY-220100	Rear absorber Assy	1		each	RX 150 XE	Rear absorber
2	GB5786-86	Bolt M6x32	1		each	RX 150 XE	Rear absorber
3	LY-220200	Connecting plate of muffler	1		each	RX 150 XE	Rear absorber
4	GB5787-86	Hexagon bolt M10x40	1		each	RX 150 XE	Rear absorber
5	GB5763-86	Hexagon nut M10	1		each	RX 150 XE	Rear absorber
6	LY-220300	Cover of rear wheel	1		each	RX 150 XE	Rear absorber
7	LY-220400	Plate of cover	1		each	RX 150 XE	Rear absorber
8	GB5763-86	Hexagon nut M16	1		each	RX 150 XE	Rear absorber
9	LY-220500	Rear wheel	1		each	RX 150 XE	Rear absorber
10	LY-220600	Rear tire	1		each	RX 150 XE	Rear absorber
11	LY-220700	Valve stem	1		each	RX 150 XE	Rear absorber
12	LY-220800	Cap of valve stem	1		each	RX 150 XE	Rear absorber
13	LY-220900	Brake shoe	2		each	RX 150 XE	Rear absorber
14	LY-221000	Spring, brake shoe	2		each	RX 150 XE	Rear absorber
15	LY-221100	Brake rocker	1		each	RX 150 XE	Rear absorber
16	LY-221200	Brake rocker shaft	1		each	RX 150 XE	Rear absorber
17	LY-221300	Spring, brake rocker	1		each	RX 150 XE	Rear absorber
18	LY-221400	O ring	2		each	RX 150 XE	Rear absorber
19	GB5787-86	Hexagon bolt M10x40	1		each	RX 150 XE	Rear absorber

F.22 - Rear absorber





Muffler							
Num.	Part No.	Description	Qty	Price	Measure	Model	Category
1	LY-230300	Muffler	1		each	RX 150 XE	Muffler
2	LY-230300	Rubber Assy	1		each	RX 150 XE	Muffler
4	LY-230300	Clip of Muffler	1		each	RX 150 XE	Muffler
5	LY-230400	Rubber of Muffler	2		each	RX 150 XE	Muffler
8	LY-230500	washer of Muffler	1		each	RX 150 XE	Muffler
9	LY-230600	washer of export Assy	1		each	RX 150 XE	Muffler
10	GB5787-86	Hexagon bolt M8x16	1		each	RX 150 XE	Muffler
11	GB5787-86	Hexagon bolt M10x30	1		each	RX 150 XE	Muffler
12	LY-230700					XE	Muffler

F.23 - Muffler



Tool KIT							
Num.	Part No.	Description	Qty	Price	Measure	Model	Category
1	LY-250200	Wrench	1		each	RX 150 XE	Tool KIT
2	LY-250200	Spoke Plug Wrench	1		each	RX 150 XE	Tool KIT
3	LY-250300	Double-End Screw Driver	1		each	RX 150 XE	Tool KIT
4	LY-250400	Open-Ended Spanner 12x14	1		each	RX 150 XE	Tool KIT
5	LY-250500	Open-Ended Spanner 8x12	1		each	RX 150 XE	Tool KIT
6	LY-251				each	RX 150 XE	Tool KIT

F.24 - Tool KIT

